

BELL 47 PARTS

93	1	47-235-013-002	FLOOR SCUFF PLATE		USED	
94	1	47-267-481-005	CABLE		NOS	
95	2	47-267-481-005	CABLE		NOS	
96	1	47-267-482-005	CABLE		NOS	
97	2	47-267-482-005	CABLE		NOS	
98	2	47-322-012-003	BRACKET		NOS	
99	1	47-323-102-001	BOOT		NOS	
100	1	47-323-103-001	REINFORCEMENT		NOS	
101	1	47-500-004-1	LEG ASSY.,FWD LH		USED	
102	1	47-500-004-10	LEG ASSY., AFT RH		NOS	
103	1	47-500-004-10	LEG ASSY.,AFT RH		USED	
104	1	47-500-004-10 G	LEG ASSY.,AFT RH		NOS	
105	1	47-500-004-2	LEG ASSY.,FWD RH		USED	
106	1	47-500-004-9	LEG ASSY., AFT LH		USED	
107	1	47-612-004-021	ADAPTER PLATE		SERVICEABLE	
108	2	47-612-123-003	GUARD		NOS	
109	1	47-612-167-015	SPINDLE		NOS	
110	1	47-612-167-015	SPINDLE		USED	
111	2	47-612-172-007	RETAINER		NOS/USED	
112	2	47-612-175-001	BUSHING,SPRAG		NOS	
113	7	47-612-176-001	BOLT		NOS	
114	8	47-612-177-001	LINK		NOS	
115	1	47-612-177-003	LINK		NOS	
116	1	47-614-050-013	PIPE		SERVICEABLE	
117	1	47-615-119-035	INLET DUCT ASSY.		USED	
ITEM	QTY.	PART NUMBER	DESCRIPTION	SERIAL NO.	CONDITION	
118	1	47-615-160-041	AIR FILTER HOUSING		USED	
119	1	47-620-015-001	SPIDER		NOS	
120	1	47-620-207-000	INC.WITH 47-620-487-1	B12-11839	SERVICEABLE	
121	1	47-620-210-005	RETAINER		NOS	
122	1	47-620-213-001	WASHER		NOS	
123	6	47-620-228-001	PINS		USED	
124	1	47-620-238-001	GEAR		NOS	
125	1	47-620-242-001	PLATE		NOS	
126	1	47-620-247-001	SLEEVE		NOS	
127	3	47-620-250-001	SHIM		NOS/USED	
128	1	47-620-251-001	GASKET		NOS	
129	1	47-620-254-001	WASHER		NOS	
130	2	47-620-299-001	WASHER		NOS	
131	2	47-620-302-001	WASHER		NOS	
132	6	47-620-349-002	RACE		NOS	
133	1	47-620-487-001	GEAR SET		SERVICEABLE	
134	2	47-620-494-003	COUPLING		USED	
135	2	47-620-499-001	NUT/WASHER		SERVICE./USED	
136	6	47-620-518-001	CAGE		NOS	
137	1	47-620-527-001	NUT		NOS	
138	3	47-620-529-001	LOCKWASHER		NOS	
139	1	47-620-530-000	INC. WITH 47-620-487-1	B12-13998	SERVICEABLE	
140	7	47-620-545-001	SHIM		NOS/USED	
141	20	47-620-547-001	SCREW/BOLT		NOS	
142	1	47-620-549-001	GEAR ASSY.		NOS	